







SMART PLUG WITH ENERGY MONITOR

Wi-Fi Outlet with Energy Monitoring, Works with Amazon Alexa, Google Home and Siri, Apple Watch, Wireless Smart Socket Remote Control Timer Switch, No Hub Required.

SKU: SHA5280
EAN: 7061256850217




Smart Control for A Smart Home

-  2.4GHz Wi-Fi Control
-  Overload Protection
-  Physical Switch
-  Timing Function
-  Many Device Connect
-  Power-OFF Protection





Energy Monitoring

Analyse a device's real-time and historical power consumption.



Voice Control

Works with Amazon Alexa and Google Assistant for Voice Control.



No Hub Required

Works with any Wi-Fi router without the need for a separate hub.

System Requirements:



Android 5.0 or higher



iOS 10 or higher

Remote Access

Control devices connected to the Smart Plug wherever you use the free ENERJSMART app on your smartphone.

Download our app


To download, Scan the QR code below



ENERJSMART



Android

iOS




Scheduling and Away Mode

Schedule the smart plug to automatically power electronics on and off; And turns your devices on and off at different times to give the appearance that someone is home.



Technical Parameters	
Model	-
Maximum Power/Load	16A (3520W)
Voltage	90-250V AC
Gang	1 Gang
Colour	White
Protocol	IEEE 802.11b/g/n
Material	PC
Operating Temperature	-20°C ~ +60°C
Connection	Wi-Fi 2.4GHz
Product Size	60*70*110mm
Product Weight	100g




Easy Set Up



1

Download the free ENERJSMART app



2

Plug the ENERJ Smart Plug into a socket



3

Follow the guide on the app

Alexa Setup

If you're new to Echo, it's a super smart speaker from Amazon that responds to your voice. Once you've bought Amazon Echo and downloaded the ENERJSMART App, you'll need to enable...



- 1. Enable the ENERJSMART App**
 In your Alexa app, tap Skills in the menu and search for ENERJSMART. Tap Enable.
- 2. Link Account**
 Enter your ENERJSMART App username and password and follow the onscreen instruction.
- 3. Talk to Alexa**
 Now the fun part Ask Alexa to control your ENERJSMART device. Check a full list of things you can control by clicking here.

Google Home Setup

Now you can use Google's voice-activated speaker to control your Smart Home Sockets and adaptors. With the Google Assistant, you can turn on lights without pressing a button.

1. Setup

Start by getting the Google Home app and setting up your Google Home if you have not done this already.

2. Add ENERJSMART Action

In the Google Home app, tap the menu icon and select Home Control. Then tap the + button to see a list of Action tapping ENERJSMART to select the Action.

3. Link you ENERJSMART Account

Now follow the in-app instructions to link you ENERJSMART App account. Once complete you'll be able to say "Okey Google, turn my lamp on" or "Okay Google, set hallway to ON/OFF".



Thank you for choosing ENER-J!

Customer satisfaction is our TOP priority, please let us know how you felt about your experience. Happy? We are so happy that you are pleased with our product. Feel free to express your newfound joy! Share your experience by writing a review.

Not Happy? If you are not fully satisfied with the item you received, have any problems like damages, or questions, please contact us. We typically respond within 24-48 hours.

Caution

Products should be installed as per the instructions mentioned in this manual and also as per current electrical codes National Electric Code (NEC). To avoid the risk of fire, electrical shock or injury, it is advisable that the installation is done by a trained Electrician. Also it is important that mains power supply is switched off before the product is installed or repaired. It is advisable to keep the manual for future reference.

Please Note

Wi-Fi frequency is 2.4GHz and not 5GHz (5GHz not supported). You can do this by contacting your broadband service provider and requesting to either switch to 2.4GHz entirely or split it between 2.4GHz and 5GHz.

If despite following the process as instructed above, you still fail to add the device, then possibly there is a firewall on your Wi-Fi router blocking this device to be connected to your Wi-Fi Router. In such a case you would need to disable the firewall, add this device following above process and once the device is added, enable the firewalls back again.

Stuck? Confused?

Contact our Technical Support team on:

T: +44 (0)2921 252 473 | E: support@ener-j.co.uk

Lines are open Mon - Fri (8am to 4pm)